



Holding clamp for the wheelchair

BJ-605-M

Holding clamp for adjustable and removable arm

It allows to firmly hold the tube of the removable and adjustable arm in a second chair.

The removable and adjustable arm has been designed for being adjusted when installed and thus, avoiding to have to adjust it continuously, so that it can maintain the same position with respects to the user. If you want to install a second clamp, we recommend to adjust it in a similar position so to maintain the benefits of the positioning of the removable arm, and avoiding to adjust the position of the arm any time that the arm of the chair is moved.



